



#### **CONTROL PANEL PARTS**

For Models: GH4155XPQ0, GH4155XPB0, GH4155XPT0 (White) (Black) (Biscuit)

MICROWAVE HOOD COMBINATION



# **DOOR PARTS**



Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
2 3 4		Black	7 8	4393777 4393782 8169642 4393833	Black Biscuit	9	8205327 8205328 8205329 8205324 8205325 8205326	Black Biscuit Frame, Outer White Black


# **INTERIOR AND VENTILATION PARTS** For Models: GH4155XPQ0, GH4155XPB0, GH4155XPT0 (White) (Black) (Biscuit) -36

## **INTERIOR AND VENTILATION PARTS**

For Models: GH4155XPQ0, GH4155XPB0, GH4155XPT0 (White) (Black) (Biscuit)

IIIus. No.	Part No.	DESCRIPTION
		DECORAL FICK
1	4393688	Reflector, Lamp
2 3	4393681	Lamp (2)
3	8169645	Filter, Charcoal
4	8169758	Filter, Grease
5	8185105	Plate, Bottom
6	8185210	Glass, Lamp
7	8184308	Holder, Glass
8	8205045	Guide, Air
0	0402022	(Magnetron)
9 10	8183823 8204656	Cover, Fan Switch, Micro (3)
11	8169438	Spring, Interlock (2)
12	8183824	Plate, Cam (2)
13	4393595	Support, Interlock (2)
14	8183825	Wheel, Fan
15	8184310	Housing, Fan
16	8185211	Motor, Fan
17	8185212	Chassis
18	8184311	Holder, Capacitor
19	8184664	
20	8169501	Capacitor, H.V.
21	8204844	Transformer, H.V.
22	8204657	Plate, Side (R)
25	8204658	Plate, Side (L)
26	4393709	Capacitor
27	8184312	Holder, Fuse
28	4393308	Fuse
29	8183703	
30	8169474	
31	4393835	
32 33	4393472 4393833	
33 34	8169478	
3 <del>4</del> 35	8169479	
36	4393839	
50	-000000	COLCAN


## **AIR FLOW PARTS**



Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Deflector, Air	9	8204751	Motor, Fan	15	4393830	Screw
2	8169557	Reflector, Air	10	8204754		16	4393874	Plate. Damper
3	8185083	Duct, Air	l 11	8184624	Housing, Fan	17		Spacer,Copper Pipe
4	8204653	Bracket, Thermostat	12		Bracket, Fan	18		Cushion, Mtr
5	8183697	Thermostat			(Not Serviced)	19		Holder, Lamp
6	8184745	Housing, Lamp	13	8169474		20	8184404	
7	4393681		14	8169478		21	4393808	Sensor, Humidity
8		Wheel, Fan	''	0.00110				

#### **MAGNETRON AND TURNTABLE PARTS**


For Models: GH4155XPQ0, GH4155XPB0, GH4155XPT0 (White) (Black) (Biscuit)



Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	8205044	Motor, Stirrer	10	4393861	Wheel, Plastic	20	4393831	Screw
2	8205315		11	8183949	Driver, Turntable	21	4393832	Screw
		Shaft/Blade	12	8183953	Motor, Turntable	23	8184485	Shield
5	8184476	Cover, Inlet	13	4393756	Cover, Terminal	24	8184585	Thermostat And
6	8204662	Hook, Rack (4)	14	8184306	Magnetron			Bracket
7	8184549	Nails/Bushings	15	8183698	Thermostat	25	8184109	Spacer
		(5 of Each)	16	8169540	Holder, Connector (L)	26		Hinge, Upper
8	4393799	Turntable	17	8169705	Holder, Connector (R)	27	8183742	Hinge, Lower
9	8184102	Ring, Turntable	18	4393838		28	8204691	
		<b>3</b> .	19	8169474	Screw			

## **CABINET AND INSTALLATION PARTS**

For Models: GH4155XPQ0, GH4155XPB0, GH4155XPT0 (White) (Black) (Biscuit)



IIIus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	8205317	Plate, Mounting	9	4393795	Grille, Holder	Misc	ellaneo	us
3		Door, Damper	10	4393833	Screw			_
4		Lid, Power Cord	13	8169318	Rod		8169659	Hardware,
6	8184898	Cord, Power	14	8169319	Latch Pivot			Installation
7		Case, Outer	15	8169320	E-Ring		8169704	Screw, Top Mountng
	8169660	White	16	8185033	Catch		8184781	Upper Template
	8169661	Black	17	8169374	Spring		8183743	Wall Template
	8169664	Biscuit	18	8169697	Plate, Damper		8204725	Rack
8		Grille, Vent			•			
	8183948	White				ACC	ESSOR'	Y PARTS
	8183851	Black						
	8183852	Biscuit						Filler Kit (Black)
							8171336	Filler Kit (White)
							8171338	Filler Kit(Biscut)